

Tool Tote Installation



1 Position your tool tote rear fender bag on the rear fender of your bike. We recommend centering the bag just behind the back edge of the seat as shown in (Fig 1).

2 While holding the bag in the desired position, drill 4 (1/4" holes) in the rear fender using the pre-drilled holes in the plastic insert at the bottom of the bag as a template. (Fig 2)

NOTE: On bikes with tail lights, be careful not to drill through the tail light wiring harness. The wiring harness is run through the right or left (depending on model) side of the black inner fender.

3 Open the supplied mounting hardware kit. (Fig 3)

4 Put one of the supplied flat washers on each of the 4 supplied 6x20mm button head bolts. Insert 1 bolt with flat washer thru each of the 4 pre-drilled holes in the bottom of the plastic insert in the bottom of the tote bag and thru the holes that you've just drilled in the rear fender.

5 On the bottom side of the fender, insert one of the supplied flat washers along with one of the supplied lock nuts on the bottom of each of the 4 mounting bolts.

6 Using a 10mm wrench to hold the lock nuts, tighten each of the 4 mounting bolts evenly using a 4mm Allen wrench.

WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and that Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. R.JRF.Sec.randt.warninganddisclaimer.5 2 08

**Enduro
Engineering**

QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

Tool Tote
Part# 22-500