

Husqvarna Rear Wheel Spacer Set Installation




FIG 1

- 1** Place motorcycle on a stand so that the rear wheel is off the ground.
- 2** Using a 27mm socket remove the rear axle nut and slide rear axle out of the swing arm and rear wheel. Lift chain off of sprocket and slide wheel out of the swing arm.
- 3** Remove the one of the old wheel spacers by pulling it out with your hand. (Figure. 1). Turn the wheel over and remove the other spacer in the same way.
- 4** Apply a thin layer of grease to the inner lip of the seals.
- 5** Push the new spacers in to the center of the wheel seals on each side of the wheel.
- 6** Slide the wheel back into swing arm and reinstall axle, adjuster plate and axle nut. Torque axle nut to manufacturer's torque specifications.
- 7** Pump rear brake pedal to make sure brake pads are seated to disc and stopping properly.

WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and that Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. R.JRF.Sec.randt.warninganddisclaimer.5 2 08



QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

Husqvarna Rear Wheel Spacer
Set Installation

Part# 16-052