



EE Honda CR/CRF/CRF-X Rear Wheel Spacer Installation Instructions

- 1** Place motorcycle on a stand so that the rear wheel is off the ground.
- 2** Using a 27mm socket remove the rear axle nut and slide rear axle out of the swing arm and rear wheel. Lift chain off of sprocket and slide wheel out of the swing arm.
- 3** Pull the wheel spacers out of the grease seals on both sides of the hub. (Figure 1)
- 4** Install new spacers in wheel seals. (Figure 2)
- 5** Slide wheel back into swing arm, lift the chain up on the sprocket and reinstall axle, adjuster plate and axle nut. Torque axle nut to motorcycle manufacturer's torque specifications. Pump rear brake pedal to make sure brake pads are seated to disc and stopping properly.



INSTRUCTIONS, WARNING AND DISCLAIMER

WARNING: Failure to read these warnings and follow these instructions could lead to loss of control of the motorcycle, an accident, severe injury or death.

WARNING: Do not ride with loose or worn wheel bearings or wheel bearing components. Always check the fasteners for tightness and that the wheels are free moving and in proper working order before every ride. **Loose, worn or inappropriately installed wheel bearings may result in loss of control, injury or death.**

CAUTION: Use only genuine Enduro Engineering replacement parts if any of the wheel bearing components become worn or damaged.

Instructions: Carefully and closely follow the installation instructions provided with these wheel bearings. **If you are not qualified to properly install this product, have the wheel bearings installed by a licensed motorcycle technician.**

If you have any questions regarding the use, fit or installation of this product, please contact your local Enduro Engineering dealer, call us at (517) 393-2421 or email us at info@enduroeng.com

WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and that Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. R.JRF.Sec.randt.warninganddisclaimer.5.2.08

Enduro Engineering

QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

EE Honda CR/CRF/CRF-X
Rear Wheel Spacer
Part# 16-650